



Open ImViewer: Double-Click on ImViewer.exe  
(file explorer or desktop)



export data  
(does not include RGB and Ratio)



select drive and folder

double click colored data file

\*.im (violet) = cameca original NanoSIMS format

\*.hdr (red) = row data with ENVI header

\*.nrrd (green) = Nearly Raw Raster Data (ImageJ)

short help

click for short help

click for file info

